

3040 RIGHT HAND RIBBON MOTOR

>>>IMPORTANT<<<

INSTALLATION INFORMATION

There have been two versions of the ribbon motors used in this printer. They can be categorized as the (old) LONG style and the (new) SHORT style. Some mounting screws which were used to install the LONG motors will be too long for the short motors and if used **WILL DAMAGE THE NEW MOTOR AND VOID THE WARRANTY**. It is extremely important that the motor be installed with all shims and washers as shown in the diagram included. Use the screws included with the replacement motor. If you notice some resistance as you tighten the mounting screws **STOP IMMEDIATELY.. DO NOT TIGHTEN THE SCREWS!** Find and use shorter screws to install the motor. Also note that in some printers the screws used on the left motor are a different length than the screws used on the right motor and cannot be mixed. **If you encounter any problems please contact our support group at 714-251-9000 for assistance.**

3040 Ribbon Motor RIGHT Inst.

1. RIBBON HUB
2. SET SCREW
3. SCREW W/LW 4-40 X .38
4. FLAT WASHER
5. CASTING
6. RIBBON MOTOR

